



CHERRY Black/Brown/Blue Switch



CHERRY Red Switch

Thank you for purchasing CM Storm Quick Fire Rapid!— an ultra compact, solid, rugged gaming keyboard using the highest grade gold plated mechanical switches (CHERRY MX) rated for over 50 million keystrokes. USB plug n play with Full 6KRO or PS/2 with Full NKRO? With QF Rapid the choice is yours!

Package Content:

- Quick Fire Rapid Mechanical Gaming Keyboard
- Extra Keycaps (6 pcs) with keycap tool
- 1.8 m braided USB cable
- USB to PS/2 Adapter
- User Guide

Warranty

2 years limited Manufacturer Warranty

Important Notice:

- * The warranty does not cover damages as a result of changing the keycaps
- * Keep out of reach of children below the Age of 10
- * Keycaps and other small objects could be swallowed

Taiwan, Asia Pacific - Cooler Master Co., Ltd.
9F, No. 786, Chung-Cheng Road, Chung-Ho City, Taipei, Taiwan, R.O.C.
Tel: +886-2-3234-0050
Service: eservice@coolermaster.com.tw

China – Cooler Master China
4F., Hui-Cheng Building, Hui-Tai industrial Park, Hui-Huan Town, Hui-Zhou City, Gunag-Dong Province, China
Tel: +86-752-260-8898
Service: web@coolermaster.com.cn

Europe - Cooler Master Europe B.V.
Hudsonweg 3 Trade Port West 9272, 5928 LW Venlo, The Netherlands
Tel: +31 (0) 77-396-8226
Service: Support@coolermaster.nl

North America - Cooler Master USA
4820 Schaefer Ave. Chino CA, 91710, USA
TEL: 909-673-9880
FAX: 909-673-9882
Service: Customersupport@coolermaster.com

Live Help
<http://www.coolermaster.com/livehelp>

Instructions for Changing the Keycaps

You can remove keycaps to:

- not accidentally hit them during game play
- because they have no particular function in your favorite game and you don't want to get distracted from the keys that do matter
- Use a differently styled set of keys
- Clean your keyboard



Whenever you plan to remove the keycaps please make sure you position the keycap tool in the center of the key, and slowly press it down all the way so both sides grip the keycap from below:



Then slowly pull the keycaps straight up. Do NOT pull them up in an angle or you might damage the key mechanism permanently!

To put a keycap back in its place, carefully position it above the mechanical switch and slowly push it straight down. If you feel a sharp rise in resistance make sure the keycap is positioned properly. Do NOT try to force it down.

*** Multi Media Keys**

Hold the Storm key down and then hit any of the F5-F12 keys for easy access to sound and media player commands

**QUICK FIRE
RAPID**